



P= Preferred
O= Optional

Vehicle Compatibility Chart

EZS7 New Self-Closing Version		Bumper Installation									Bed Installation			
		Vehicle Side			Trailer Side		Installation Clips*			Vehicle Side		Trailer Side		
Years	Make and Model	S7-05	S7-06	S7-06D	S7-07	S7-07-06	S7-60G	S7-60F	S7-61	S7-08	S7-09	S7-09D	S7-10	
2008-2013	Buick Enclave w/Factory 7-Way	O	P		P	O	P		O					
2004-2007	Buick Rainier w/Factory 7-Way	O	P		P	O	P		O					
2003-2012	Cadillac Escalade ESV w/Factory 7-Way	O	P		P	O	P		O					
2002-2012	Cadillac Escalade EXT w/Factory 7-Way	O	P		P	O	P		O					
2002-2012	Cadillac Escalade w/Factory 7-Way	O	P		P	O	P		O					
2002-2012	Chevrolet Avalanche w/Factory 7-Way	O	P		P	O	P		O					
2008-2012	Chevrolet Colorado w/Factory 7-Way	O	P		P	O	P		O	O	P		P	
2008-2012	Chevrolet Equinox w/Factory 7-Way	O	P		P	O	P		O					
2003-2012	Chevrolet Express Van w/Factory 7-Way	O	P		P	O	P		O					
2003-2012	Chevrolet Pickup, Silverado 1500 w/Factory 7-Way	O	P		P	O	P		O	O	P		P	
1999-2012	Chevrolet Pickup, Silverado 2500 w/Factory 7-Way	O	P		P	O	P		O	O	P		P	
1999-2012	Chevrolet Pickup, Silverado 3500 w/Factory 7-Way	O	P		P	O	P		O	O	P		P	
2000-2012	Chevrolet Suburban New Body Style w/Amber Turn Signals w/Factory 7-Way	O	P		P	O	P		O					
2000-2012	Chevrolet Tahoe New Body Style w/Amber Turn Signals w/Factory 7-Way	O	P		P	O	P		O					
2002-2009	Chevrolet TrailBlazer w/Factory 7-Way	O	P		P	O	P		O					
2009-2012	Chevrolet Traverse w/Factory 7-Way	O	P		P	O	P		O					
2007-2009	Chrysler Aspen w/Factory 7-Way	O		P	P	O			P					
1995-2008	Dodge Pickup, Dakota, Only w/Factory 7-Way	O		P	P	O			P	O		P	P	
1995-2008	Dodge Pickup, Ram, Full Size 1500 Only w/Factory 7-Way	O		P	P	O			P	O		P	P	
2009-2012	Dodge Pickup, Ram, Full Size 1500 Only w/Factory 7-Way	O	P		P	O			P	O	P		P	
1995-2009	Dodge Pickup, Ram, Full Size 2500-3500 HD Only w/Factory 7-Way	O		P	P	O			P	O		P	P	
2010-2012	Dodge Pickup, Ram, Full Size 2500-3500 w/Factory 7-Way	O	P		P	O			P	O	P		P	
2004-2007	Ford E-Van w/Factory 7-Way	O	P		P	O			P					
2008-2012	Ford E-Van w/Factory 7-Way	O	P		P	O		P	O					

*Installation Clips- Are to be used for easy bumper installation of the EZS7

The S7-60F and S7-60G are the preferred option when compatible (please refer to chart). However, the S7-61 is a pre-drilled and tapped mounting bracket for installation on vehicles lacking the factory (OEM) hole or mounting bracket. It is always recommended when using the S7-05 and optional when using the S7-06.

EZS7 New Self-Closing Version		Bumper Installation									Bed Installation			
		Vehicle Side			Trailer Side		Installation Clips			Vehicle Side			Trailer Side	
Years	Make and Model	S7-05	S7-06	S7-06D	S7-07	S7-07-06	S7-60G	S7-60F	S7-61	S7-08	S7-09	S7-09D	S7-10	
2000-2005	Ford Excursion w/Factory 7-Way	O	P		P	O			P					
1999-2007	Ford Expedition w/Factory 7-Way	O	P		P	O			P					
2008-2012	Ford Expedition w/Factory 7-Way	O	P		P	O		P	O					
2002-2007	Ford Explorer w/Factory 7-Way	O	P		P	O			P					
2008-2013	Ford Explorer w/Factory 7-Way	O	P		P	O		P	O					
2004-2007	Ford F-150 (New Body Style) w/Factory 7-Way	O	P		P	O			P	O	P		P	
2008-2012	Ford F-150 (New Body Style) w/Factory 7-Way	O	P		P	O		P	O	O	P		P	
1997-2003	Ford F-150 Light Duty Flareside w/Factory 7-Way	O	P		P	O			P	O	P		P	
2004-2004	Ford F-150 Light Duty Heritage (Old Body Style) w/Factory 7-Way	O	P		P	O		P	O	P			P	
1997-2003	Ford F-150 Light Duty Styleside w/Factory 7-Way	O	P		P	O			P	O	P		P	
1997-1999	Ford F-250 Light Duty Styleside w/Factory 7-Way	O	P		P	O			P	O	P		P	
1999-2007	Ford F-250 Super Duty w/Factory 7-Way	O	P		P	O			P	O	P		P	
2008-2012	Ford F-250 Super Duty w/Factory 7-Way	O	P		P	O		P	O	O	P		P	
1999-2007	Ford F-350 Super Duty w/Factory 7-Way	O	P		P	O			P	O	P		P	
2008-2012	Ford F-350 Super Duty w/Factory 7-Way	O	P		P	O		P	O	O	P		P	
1999-2007	Ford F-450 Super Duty w/Factory 7-Way	O	P		P	O			P	O	P		P	
2008-2012	Ford F-450 Super Duty w/Factory 7-Way	O	P		P	O		P	O	O	P		P	
1999-2007	Ford F-550 Super Duty w/Factory 7-Way	O	P		P	O			P	O	P		P	
2008-2010	Ford F-550 Super Duty w/Factory 7-Way	O	P		P	O		P	O	O	P		P	
2007-2012	GMC Acadia w/Factory 7-Way	O	P		P	O	P		O					
2008-2012	GMC Canyon w/Factory 7-Way	O	P		P	O	P		O	O	P		P	
2002-2010	GMC Envoy w/Factory 7-Way	O	P		P	O	P		O					
2007-2007	GMC Pickup, Sierra Classic w/Factory 7-Way	O	P		P	O	P		O	O	P		P	
2007-2012	GMC Pickup, Sierra New Body Style w/Factory 7-Way	O	P		P	O	P		O	O	P		P	
1999-2006	GMC Pickup, Sierra w/Factory 7-Way	O	P		P	O	P		O	O	P		P	
2009-2012	GMC Savana Van w/Factory 7-Way	O	P		P	O	P		O					
2012-2012	GMC Terrain w/Factory 7-Way	O	P		P	O	P		O					
2001-2012	GMC Yukon Denali New Body Style w/Amber Turn Signals w/Factory 7-Way	O	P		P	O	P		O					

*Installation Clips- Are to be used for easy bumper installation of the EZS7

The S7-60F and S7-60G are the preferred option when compatible (please refer to chart). However, the S7-61 is a pre-drilled and tapped mounting bracket for installation on vehicles lacking the factory (OEM) hole or mounting bracket. It is always recommended when using the S7-05 and optional when using the S7-06.

EZS7 New Self-Closing Version		Bumper Installation									Bed Installation			
		Vehicle Side			Trailer Side		Installation Clips			Vehicle Side		Trailer Side		
Years	Make and Model	S7-05	S7-06	S7-06D	S7-07	S7-07-06	S7-60G	S7-60F	S7-61	S7-08	S7-09	S7-09D	S7-10	
2000-2012	GMC Yukon New Body Style w/Amber Turn Signals w/Factory 7-Way	O	P		P	O	P		O					
2001-2012	GMC Yukon XL Denali w/Factory 7-Way	O	P		P	O	P		O					
2000-2012	GMC Yukon XL w/Factory 7-Way	O	P		P	O	P		O					
2005-2009	Hummer H2 SUT w/Factory 7-Way	O	P		P	O	P		O					
2003-2009	Hummer H2 w/Factory 7-Way	O	P		P	O	P		O					
2006-2009	Hummer H3 w/Factory 7-Way	O	P		P	O	P		O					
2009-2009	Hummer H3T w/Factory 7-Way	O	P		P	O	P		O					
2004-2012	Infiniti QX56 w/Factory 7-Way	O	P		P	O			P					
2003-2008	Isuzu Ascender w/Factory 7-Way	O	P		P	O			P					
1998-2012	Jeep Grand Cherokee w/Factory 7-Way	O	P		P	O			P					
2008-2012	Jeep Liberty w/Factory 7-Way	O	P		P	O			P					
2009-2010	KIA Borrego w/Factory 7-Way	O	P		P	O			P					
2003-2006	Lincoln Aviator w/Factory 7-Way	O	P		P	O			P					
2006-2007	Lincoln Mark LT w/Factory 7-Way	O	P		P	O			P	O	P		P	
2008-2008	Lincoln Mark LT w/Factory 7-Way	O	P		P	O			P					
1999-2007	Lincoln Navigator w/Factory 7-Way	O	P		P	O			P					
2008-2012	Lincoln Navigator w/Factory 7-Way	O	P		P	O			P					
2002-2007	Mercury Mountaineer w/Factory 7-Way	O	P		P	O			P					
2008-2010	Mercury Mountaineer w/Factory 7-Way	O	P		P	O			P					
2004-2012	Nissan Armada w/Factory 7-Way	O	P		P	O	P		O					
2004-2012	Nissan Pathfinder w/Factory 7-Way	O	P		P	O	P		O					
2004-2012	Nissan Titan Pickup w/Factory 7-Way	O	P		P	O	P		O	O	P		P	
2002-2004	Oldsmobile Bravada w/Factory 7-Way	O	P		P	O	P		O					
2005-2009	Saab 9-7X w/Factory 7-Way	O	P		P	O			P					
2007-2009	Saturn Outlook w/Factory 7-Way	O	P		P	O			P					
2010-2012	Toyota 4Runner w/Factory 7-Way	O	P		P	O		P	O					
2010-2012	Toyota FJ Cruiser w/Factory 7-Way	O	P		P	O	P		P					
2010-2012	Toyota Highlander w/Factory 7-Way	O	P		P	O	P		P					

*Installation Clips- Are to be used for easy bumper installation of the EZS7

The **S7-60F** and **S7-60G** are the preferred option when compatible (please refer to chart). However, the **S7-61** is a pre-drilled and tapped mounting bracket for installation on vehicles lacking the factory (OEM) hole or mounting bracket. It is always recommended when using the S7-05 and optional when using the S7-06.

EZS7 New Self-Closing Version		Bumper Installation							Bed Installation				
Years	Make and Model	Vehicle Side			Trailer Side		Installation Clips			Vehicle Side		Trailer Side	
		S7-05	S7-06	S7-06D	S7-07	S7-07-06	S7-60G	S7-60F	S7-61	S7-08	S7-09	S7-09D	S7-10
2010-2013	Toyota Land Cruiser w/Factory 7-Way	O	P		P	O			P	O			
2010-2012	Toyota Sequoia w/Factory 7-Way	O	P		P	O			P	O			
2010-2012	Toyota Tacoma w/Factory 7-Way	O	P		P	O			P	O	O	P	P
2010-2012	Toyota Tundra w/Factory 7-Way	O	P		P	O			P	O	O	P	P
All Years	***I do not see my vehicle***	P			P	O			P	P	P		P

*Installation Clips- Are to be used for easy bumper installation of the EZS7

The S7-60F and S7-60G are the preferred option when compatible (please refer to chart). However, the S7-61 is a pre-drilled and tapped mounting bracket for installation on vehicles lacking the factory (OEM) hole or mounting bracket. It is always recommended when using the S7-05 and optional when using the S7-06.

EZR7 Original Version with Dummy Plug		Bumper Installation							
Years	Make and Model	Complete Kits			Vehicle Side		Trailer Side		
		R7-01	R7-02	R7-02D	R7-05	R7-06	R7-06D	R7-07	
2008-2013	Buick Enclave w/Factory 7-Way	O	P		O	P		P	
2004-2007	Buick Rainier w/Factory 7-Way	O	P		O	P		P	
2003-2012	Cadillac Escalade ESV w/Factory 7-Way	O	P		O	P		P	
2002-2012	Cadillac Escalade EXT w/Factory 7-Way	O	P		O	P		P	
2002-2012	Cadillac Escalade w/Factory 7-Way	O	P		O	P		P	
2002-2012	Chevrolet Avalanche w/Factory 7-Way	O	P		O	P		P	
2008-2012	Chevrolet Colorado w/Factory 7-Way	O	P		O	P		P	
2008-2012	Chevrolet Equinox w/Factory 7-Way	O	P		O	P		P	
2003-2012	Chevrolet Express Van w/Factory 7-Way	O	P		O	P		P	
2003-2012	Chevrolet Pickup, Silverado 1500 w/Factory 7-Way	O	P		O	P		P	
1999-2012	Chevrolet Pickup, Silverado 2500 w/Factory 7-Way	O	P		O	P		P	
1999-2012	Chevrolet Pickup, Silverado 3500 w/Factory 7-Way	O	P		O	P		P	
2000-2012	Chevrolet Suburban New Body Style w/Amber Turn Signals w/Factory 7-Way	O	P		O	P		P	
2000-2012	Chevrolet Tahoe New Body Style w/Amber Turn Signals w/Factory 7-Way	O	P		O	P		P	
2002-2009	Chevrolet TrailBlazer w/Factory 7-Way	O	P		O	P		P	
2009-2012	Chevrolet Traverse w/Factory 7-Way	O	P		O	P		P	
2007-2009	Chrysler Aspen w/Factory 7-Way	O			P	O		P	P
1995-2008	Dodge Pickup, Dakota, Only w/Factory 7-Way	O			P	O		P	P
1995-2008	Dodge Pickup, Ram, Full Size 1500 Only w/Factory 7-Way	O			P	O		P	P

P= Preferred

O= Optional

EZR7 Original Version with Dummy Plug		Bumper Installation						
		Complete Kits			Vehicle Side		Trailer Side	
Years	Make and Model	R7-01	R7-02	R7-02D	R7-05	R7-06	R7-06D	R7-07
2009-2012	Dodge Pickup, Ram, Full Size 1500 Only w/Factory 7-Way	O	P		O	P		P
1995-2009	Dodge Pickup, Ram, Full Size 2500-3500 HD Only w/Factory 7-Way	O		P	O		P	P
2010-2012	Dodge Pickup, Ram, Full Size 2500-3500 w/Factory 7-Way	O	P		O	P		P
2004-2012	Ford E-Van w/Factory 7-Way	O	P		O	P		P
2000-2005	Ford Excursion w/Factory 7-Way	O	P		O	P		P
1999-2012	Ford Expedition w/Factory 7-Way	O	P		O	P		P
2002-2013	Ford Explorer w/Factory 7-Way	O	P		O	P		P
2004-2012	Ford F-150 (New Body Style) w/Factory 7-Way	O	P		O	P		P
1997-2003	Ford F-150 Light Duty Flareside w/Factory 7-Way	O	P		O	P		P
2004-2004	Ford F-150 Light Duty Heritage (Old Body Style) w/Factory 7-Way	O	P		O	P		P
1997-2003	Ford F-150 Light Duty Styleside w/Factory 7-Way	O	P		O	P		P
1997-1999	Ford F-250 Light Duty Styleside w/Factory 7-Way	O	P		O	P		P
1999-2012	Ford F-250 Super Duty w/Factory 7-Way	O	P		O	P		P
1999-2012	Ford F-350 Super Duty w/Factory 7-Way	O	P		O	P		P
1999-2012	Ford F-450 Super Duty w/Factory 7-Way	O	P		O	P		P
1999-2010	Ford F-550 Super Duty w/Factory 7-Way	O	P		O	P		P
2007-2012	GMC Acadia w/Factory 7-Way	O	P		O	P		P
2008-2012	GMC Canyon w/Factory 7-Way	O	P		O	P		P
2002-2010	GMC Envoy w/Factory 7-Way	O	P		O	P		P
2007-2007	GMC Pickup, Sierra Classic w/Factory 7-Way	O	P		O	P		P
2007-2012	GMC Pickup, Sierra New Body Style w/Factory 7-Way	O	P		O	P		P
1999-2006	GMC Pickup, Sierra w/Factory 7-Way	O	P		O	P		P
2009-2012	GMC Savana Van w/Factory 7-Way	O	P		O	P		P
2012-2012	GMC Terrain w/Factory 7-Way	O	P		O	P		P
2001-2012	GMC Yukon Denali New Body Style w/Amber Turn Signals w/Factory 7-Way	O	P		O	P		P
2000-2012	GMC Yukon New Body Style w/Amber Turn Signals w/Factory 7-Way	O	P		O	P		P
2001-2012	GMC Yukon XL Denali w/Factory 7-Way	O	P		O	P		P
2000-2012	GMC Yukon XL w/Factory 7-Way	O	P		O	P		P
2005-2009	Hummer H2 SUT w/Factory 7-Way	O	P		O	P		P
2003-2009	Hummer H2 w/Factory 7-Way	O	P		O	P		P
2006-2009	Hummer H3 w/Factory 7-Way	O	P		O	P		P

P= Preferred
O= Optional

EZR7 Original Version with Dummy Plug		Bumper Installation						
		Complete Kits			Vehicle Side		Trailer Side	
Years	Make and Model	R7-01	R7-02	R7-02D	R7-05	R7-06	R7-06D	R7-07
2009-2009	Hummer H3T w/Factory 7-Way	O	P		O	P		P
2004-2012	Infiniti QX56 w/Factory 7-Way	O	P		O	P		P
2003-2008	Isuzu Ascender w/Factory 7-Way	O	P		O	P		P
1998-2012	Jeep Grand Cherokee w/Factory 7-Way	O	P		O	P		P
2008-2012	Jeep Liberty w/Factory 7-Way	O	P		O	P		P
2009-2010	KIA Borrego w/Factory 7-Way	O	P		O	P		P
2003-2006	Lincoln Aviator w/Factory 7-Way	O	P		O	P		P
2006-2008	Lincoln Mark LT w/Factory 7-Way	O	P		O	P		P
1999-2012	Lincoln Navigator w/Factory 7-Way	O	P		O	P		P
2002-2010	Mercury Mountaineer w/Factory 7-Way	O	P		O	P		P
2004-2012	Nissan Armada w/Factory 7-Way	O	P		O	P		P
2004-2012	Nissan Pathfinder w/Factory 7-Way	O	P		O	P		P
2004-2012	Nissan Titan Pickup w/Factory 7-Way	O	P		O	P		P
2002-2004	Oldsmobile Bravada w/Factory 7-Way	O	P		O	P		P
2005-2009	Saab 9-7X w/Factory 7-Way	O	P		O	P		P
2007-2009	Saturn Outlook w/Factory 7-Way	O	P		O	P		P
2010-2012	Toyota 4Runner w/Factory 7-Way	O	P		O	P		P
2010-2012	Toyota FJ Cruiser w/Factory 7-Way	O	P		O	P		P
2010-2012	Toyota Highlander w/Factory 7-Way	O	P		O	P		P
2010-2013	Toyota Land Cruiser w/Factory 7-Way	O	P		O	P		P
2010-2012	Toyota Sequoia w/Factory 7-Way	O	P		O	P		P
2010-2012	Toyota Tacoma w/Factory 7-Way	O	P		O	P		P
2010-2012	Toyota Tundra w/Factory 7-Way	O	P		O	P		P
All Years	***I do not see my vehicle***	P			P			P

P= Preferred

O= Optional

Adapters					
Years	Make and Model	R7-51	R7-52	R7-54	R7-56
All Years	All Makes and Models	P	P	P	P